Cannabis Cutting Solutions


With over an **estimated 50,000** commercial uses, Cannabis products reach across several industries. Rely on Urschel as your partner in productivity for many of these size reduction applications.



Milk Production

Oil/Capsule Production

Cannabis Buds (Input)





Cannabis/Hemp Input

Reduction on 3600F

Reduction on 3600F

Reduction on 1700

Delivering Size Reduction Solutions to Targeted Markets

Urschel reduction machinery is widely used by leading processors worldwide, since 1910. Customers in niche and target markets rely on Urschel's expertise to assist them in pioneering new markets and new products. Providing batch and high volume lines with efficient, profitable approaches. Stainless steel, sanitary design. Operation at the push of a button. Clean and precise in-spec cuts throughout production runs to deliver increased profits. Explore Urschel resources and expert knowledge. Urschel equips you with the best in cutting machinery to meet your production goals.



Comitrol[®] Processor Model 1700 🌆 😂 🏢

The Comitrol Processor Model 1700's versatile operating principle enables slicing as well as particle size reduction. Choose between the 3

different styles of reduction heads.

Sealed enclosure deters escape of dust or vapors, when installed with a collection system.

Comitrol® Processor Models

3600SL & 3600F

The Comitrol Processor Models 3600 Slant and

3600 with Feeder are

ideal for small volume to high capacity production. Processors benefit from the

wide selection of cutting

heads to chop, flake cut,

Either model may be used

as a precutter to the Model

1700. The 3600F includes

a screw feeder to support


positive feeding of product.

or mill.




Reductions





Slicing Head Slices: .020 to .060" (.5 to 1.5 mm).





Microcut Head

Offers the smallest in particle size from .0012 to .0237" (.03 to .6 mm).





Cutting Head

Offers particle size from .010 to 1.5" (.254 to 38.1 mm).

Cutting Overview

- 1. Impeller
- 2. Slicing Knife
- 3. Horizontal Separators
 - nzonnai separators
- 4. Vertical Knives
- 5. Blades

eparators

The Comitrol incrementally shears product to achieve consistent, uniform particle size. Other methods employ types of grinding or tearing action which may produce excessive heat and degrade the quality of the finished product.



www.urschel.com

info@<u>urschel.com</u>